



ATMEGA48A

29	RESET(PC6)	12	B3
20	AREF	13	B1
4	UCC	14	BUZZER
3	GND	15	B5
6	UCC2	16	START
5	GND2	17	B6
18	AUCC	7	B4
21	GND3	8	B2
		23	DIP0
		24	DIP1
		25	DIP2
		26	DIP3
		27	DIP4
		28	DIP5
		19	BATT
		22	VOL
		30	DIP6
		31	DIP7
		32	DIP8
		1	DIP9
		2	
		9	
		10	
		11	

SETTINGS

